



Perspective View



Top View



Front View

General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure.
Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly


- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




Spline Connection



Base Plate & Extrusion Connection



Extrusion & Lock Connection



Engaged Lock



WARNING



DO NOT USE POWER TOOLS




LADDERS OR LIFTS
MAY BE REQUIRED




ALL CONNECTIONS MUST
BE TIGHTLY SECURED


Top View of Each Level



Level 1 (Bottom Level)



Level 2




Level 3


Literature Holders

Setup Hardware
w/ Shelf Supports


Top View of Each Level




Level 1 (Bottom Level)



Level 2




Level 3






Item	Qty.	Description
1	1	38" RR91 Vertical Extrusion w/ Door Stop
2	1	38" RR91 Vertical Extrusion w/ Door Hinges
3	1	40" RR91 Vertical Extrusion
4	1	40" RR91 Vertical Extrusion
5,5A	1,1	18.0868" Z45 Curved Horizontal Extrusion
6,6A	1,1	13" Z45 Horizontal Extrusion
7,7A	1,1	13" Z45 Horizontal Extrusion
8,8A	1,1	14" Z45 Horizontal Extrusion

Steps:

- 1) Attach lower horizontals [5] [6] [7] and [8] between verticals [1] [2] [3] and [4].
- 2) Slide infills between [1] [4], [2] [3], and [3] [4], making sure Velcro is facing inward.
- 3) Connect door to vertical [2]. See [Door Connection](#) detail.
- 4) Attach upper horizontals [5A] [6A] [7A] and [8A] between verticals [1] [2] [3] and [4] to secure infills.









Partial Assembly



Steps:

- 1) Connect shelf supports to Velcro on infills, then place shelf on top of supports.
- 2) Lock counter top to horizontals [6A] and [7A]. See [Counter Top Lock](#) detail.
- 3) Attach upper verticals [9] to lower verticals [3] and [4]. See [Extrusion Connector](#) detail.
- 4) Attach horizontal [10] between verticals [9].
- 5) Attach monitor mount to verticals [9]. See [Monitor Mount Attachment](#) detail.
- 6) Attach literature holders to vertical [2]. See [Literature Holder Attachment](#) detail.

Item	Qty.	Description
9	2	35" RR91 Vertical Extrusion
10	1	14" Z45 Horizontal Extrusion



Completed Assembly

