



General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




MARNING




Spline Connection



Base Plate & Extrusion Connection





Extrusion & Lock Connection



DO NOT USE POWER TOOLS



LADDERS OR LIFTS MAY BE REQUIRED



ALL CONNECTIONS MUST BE TIGHTLY SECURED





Side-by-Side Assembly


- 1) Frames: Place frames side-by-side with one higher than the other, then slide panel down to lock panels securely together.
- 2) Corner Connectors: Repeat Step 1 for installing corner connectors to frames.


Side-by-Side Disassembly

- 1) Pull pin lock outwards to disengage.
- 2) Pull frames upward and apart at the same time to detatch.










Top View Note: Orientation of Corner Connector may change.


Stacking Assembly


- 1) Place one horizontal frame on top of the other, lining up the center grooves.
- 2) Turn stacking lock clockwise to tighten into place. Repeat for each lock.

Stacking Disassembly


- 1) Turn the stacking lock counter-clockwise to loosen.
- 2) The whole spring on the stacking lock should be in view to release each frame. The disengaged spring should release the stacking lock. If not, keep turning the stacking lock until it disengages.







It is important to first insert graphic into each alternate corner then to the sides of the frame. If this is not done, graphic will not fit into the frame correctly.



Step 1 Insert corner A. Turn edge of graphic so silicon welt is perpendicular to face of graphic. Insert narrow side of welt with fabric to outside into the channel. Repeat for other side of this corner.




Step 2 Repeat Step 1 for opposite corner C, then insert corner B, followed by corner D, to complete the installation of the corners.



Step 3 Once all corners are inserted, press one silicon edge into channel from corners and work toward the center. Make sure welt is fully inserted into channel. Continue until all sides are done. Smooth out edges of graphic.

Graphic Removal



To remove the graphic from the frame, locate the fabric pull tab. Gently pull up on the tab to remove the fabric.

16

Order #XXXXX Closet Assembly

Steps:


Top View

© 2022


Description Item Qty. 38"w x 95"h Gravitee Panel 94.5"h Gravitee Corner Post w/ caps 38"w x 95"h Gravitee Panel 94.5"h Gravitee Corner Post w/ caps 38"w x 95"h Gravitee Panel w/ Door 38"w x 95"h Gravitee Panel 94.5"h Gravitee Corner Post w/ caps 10 11 38"w x 95"h Gravitee Panel 12 38"w x 95"h Gravitee Panel 38"w x 95"h Gravitee Panel 13 14 38"w x 95"h Gravitee Panel 94.5"h Gravitee Corner Post w/ caps 15

Refer to the Gravitee Assembly general information page.

1) Assemble Gravitee panels & posts [1] through [16] in numerical order as shown.



When assembled





Steps:

© 2022

Refer to the SEG Installation general information page.

1) Apply SEG graphics to outside face of panels & door.





When assembled